



BANK0/3 VOLTAGE (JTAG IO)
 3.3V default (Not recommended to change)